



## **LM102 Electric Diaphragm Fuel Pump** **Fitting Instructions**

This fuel pump model is specifically designed for installation in the engine bay, at or near the level of the carburettor.

If installed in any other position, performance will be reduced so should not be carried out.

If you are not installing in the designed position, please refer to supplier for an alternative model to suit your requirements.

*[www.fueelflow2020.nz](http://www.fueelflow2020.nz)*